



1


5V minimum 2.0A




2



3



4



5 ON / OFF

ON

3 s



OFF

3 s



exibel®

Exibel Boom-X
39-1293

Complete manual

www.clasohlson.uk

www.clasohlson.se


www.clasohlson.no

www.clasohlson.fi


www.clasohlson.de

Two Speaker Connection with TWS (True Wireless Stereo)


TWS ON




Left Speaker




Right Speaker




Left Speaker




Right Speaker





Left Speaker



Right Speaker



5



TWS OFF

