



1


Case




Earbuds




2




3




4



5 ON/OFF



6 Factory reset



exibel®

Exibel Dunite
39-2235-1
39-2235-2

Complete manual
www.clasohlson.uk
www.clasohlson.se
www.clasohlson.no
www.clasohlson.fi
www.clasohlson.de